




AZTECH CONVERTING SYSTEMS
212 W Lodge Drive
TEMPE, AZ 85283
PHONE (480) 951-8351
FAX (480) 998-5409
www.aztechconverting.com

ROLL RUNNER User Manual MH-1500





AZTECH CONVERTING SYSTEMS

**MH-1500
USER MANUAL**

TABLE OF CONTENTS

| | |
|---|-------------|
| SECTION 1: GENERAL INFORMATION | 1-4 |
| SECTION 2: MACHINE SETUP | 4 |
| SECTION 3: MACHINE OPERATION | 5-7 |
| SECTION 4: MAINTENANCE AND REPAIRS | 8 |
| SECTION 5: CART DETAIL | 9-16 |
| SECTION 6: REPLACEMENT PARTS | 17 |
| SECTION 7: WARRANTIES AND SERVICE | 18 |



Section 1: General Information

1-1: Introduction

The AZTECH RollRunner Model MH-1500 Roll Handling Cart is designed and manufactured to help reduce workplace injuries by performing various material handling functions utilizing AZTECH's innovative quick-change attachment system. The RollRunner with its all-steel construction and simplistic design will prove to be an invaluable product for your work environment and is sure to provide your company many years of safe, dependable service.

1-2: Machine Information and Specifications




Fig. 1-1: MAX LIFT HEIGHTS

The MH-1500 operates on a chain and electric winch lift system. The lift height is limited by the height of the upright boom. Currently, two different standard lift heights are offered. They are the 1500A and 1500B. Their respective maximum lifts are shown in Fig. 1-1.



AZTECH CONVERTING SYSTEMS

MH-1500 USER MANUAL

MH-1500A

MAX LOAD: 1500 LBS (680 kg)

MAX Lift Height: 48 (106 cm)

Dimensions: 28.25 X 34 X 57.25

All dimensions are inches unless otherwise specified







Fig. 1-2: THE MH-1500A

AZTECH CONVERTING SYSTEMS

MH-1500
USER MANUAL



MH-1500B

MAX LOAD: 1500 LBS (680 kg)

MAX Lift Height: 63 (160 cm)

Dimensions: 28.25 X 34 X 50.75

All dimensions are inches unless otherwise specified





Fig. 1-3: THE MH-1500B



AZTECH CONVERTING SYSTEMS

MH-1500 USER MANUAL

1-3: Care and Maintenance

The RollRunner is relatively maintenance free, with the only scheduled maintenance being to grease the xerxe fitting monthly on the transmission and to charge and maintain water levels for the battery as needed.

1-4: Safety

The RollRunner MH1500 Series is equipped with an E-Stop Switch (see Figure 1-4) which may be used to shut off the power in the event of a machine malfunction . To shut off power, depress the switch, and to restore power pull the switch.

NEVER:

- Operate the ROLL RUNNER without the safety cover.*
- Lift load over people*
- Exceed the 1500 LB weight limitation*
- Use the ROLL RUNNER to transport people*

Section 2: Machine Setup

2-1: Uncrating & Inspection

After carefully removing your RollRunner from the crate, check to assure that all the bolts are tight and that no components have come loose during shipment. Carefully inspect all 4 wheels making sure they roll freely and are free of damage. If any visible damage has occurred in shipment, contact AZTECH immediately.



Section 3: Machine Operation




Fig. 3-1: MACHINE CONTROLS

3-1: Operating Lift

To operate the lift, pull the E-Stop knob to enable lift. Using the toggle switch immediately below, raise and lower the lift. (See Figure 3-1)

There is a weight limit interrupt switch built in to the machine. If the lift will not raise, lower the carriage, inspect the load and retry.

3-2: Rear Wheel Safety Brakes

The RollRunner is equipped with back wheel safety brakes which are to be used to hold the cart in place once in desired position and as a safety feature to keep the cart from rolling while in the stationary position. To operate, simply press handle down and snap into place to activate brake, and lift to de-activate brake.




Fig. 3-2: THE SAFETY BRAKE




AZTECH CONVERTING SYSTEMS

MH-1500 USER MANUAL


3-3 Changing Attachments

The Rollrunner utilizes a EZ Change Attachment System which makes it capable of performing numerous tasks. To change attachments, simply lift attachment off the trolley and lower into place making certain that retainer tab slides into the Slot at the top of the trolley.


3-4: Available Attachments



Roller Core Boom: For loading and unloading rolls from the side position by supporting the roll through the roll's core.




The Roller Core Boom may be ordered in several lengths to best fit your application. Contact your AZTECH service representative for more details.





AZTECH CONVERTING SYSTEMS

MH-1500
USER MANUAL



360 Degree Swivel-Cradle:

Supports the roll from the bottom and can be turned 360 degrees for precise alignment.



TWO POINT LIFT:

Supports the roll through the arbor. Typically used for loading and unloading cradle-mount arbors.

The lift frame is made to order, dimensions are application specific.



AZTECH CONVERTING SYSTEMS

MH-1500 USER MANUAL

Section 4: Maintenance and Repairs

4-1 Periodic Inspections

To keep your RollRunner operating properly, AZTECH recommends performing the following periodic inspection:

- Inspect chain lift. If any wear or damage is found, replace chain immediately.
- Inspect the pulley on the trolley to assure that it turns easily.
- Inspect the lift attachment(s). If any cracks or damage is found, have the attachment repaired or replaced.
- Inspect the springs on the safety brake to assure they are connected at both ends.
- Inspect the toe brake on the rear heels for proper operation.

4-2: Battery Recommendations

Due to shipping restrictions, your Roll Runner MH1500 does not come with a battery. Suitable 12V batteries are available from most auto part or hardware stores. Choose the model with the highest CCA (Cold Cranking Amps) rating. For longer life, a marine “deep cycle” battery is recommended.

Suggested models are:

- 24MD-DL
- 24DC


AZTECH CONVERTING SYSTEMS

MH-1500 USER MANUAL



Section 5: Station Details

Section 5-1: Trolley Assembly




| ITEM NO. | PART NUMBER | DESCRIPTION | QTY. |
|----------|------------------------------------|--|------|
| 1 | 14991 | MH150 TRANSMISSION CHAIN LIFT TROLLEY WELDMENT | 1 |
| 2 | 14567 | MH150 CHAIN LIFT TROLLEY CHAIN CLAMP PLATE | 1 |
| 3 | 18965 | 2" DIA X 5/8ID CAM FOLLOWER | 4 |
| 4 | 5_8-14GA N RIM WASHER | 5/8 14 GA N RIM WASHER | 28 |
| 5 | 18972 | 5/8 SET COLLAR | 4 |
| 6 | 14571 | MH150 CHAIN LIFT TROLLEY THRUST WHEEL | 4 |
| 7 | 1_2 X 5_8 X 1 INCH | BUSHING 6391K215 | 4 |
| 8 | 14568 | MH150 CHAIN LIFT TROLLEY THRUST PLATE WELDMENT | 2 |
| 9 | HEX NUT _500-13 UNC 0 LOCK | NYLOCK NUT 1/2-13 | 4 |
| 10 | HEX BOLT _500-13 UNC 2-25 SIMP | HEX BOLT 1/2-13 X 2-1/4" GRADE 5 | 4 |
| 11 | HEX BOLT _375-16 UNC 1-5 SIMP | HEX BOLT 3/8-16 X 1-1/2" | 4 |
| 12 | SSCR-HEX-CUP _250-20 UNC 0-75 SIMP | SOCKET SET SCREW 1/4-20 X 3/4" | 4 |
| 13 | 14572 | MH150 CHAIN LIFT TROLLEY BEARING SUPPORT SHAFT | 2 |
| 14 | CLIP-SH_SH-62 | EXT 5/8 DIA SNAP RING | 4 |
| 15 | 15054 | MH150 TRANSMISSION CHAIN LIFT TROLLEY STANDOFF | 2 |
| 16 | HEX BOLT _500-13 UNC 1 SIMP | HEX BOLT 1/2-13 X 1" | 4 |
| 17 | 1 IN SET COLLAR | 1" SET COLLAR | 2 |



AZTECH CONVERTING SYSTEMS

MH-1500 USER MANUAL

Section 5-2: Transmission Assembly




| ITEM NO. | PART NUMBER | DESCRIPTION | BRAKE SERVICE/QTY. |
|----------|---|---|--------------------|
| 1 | 14707 | MH150 TRANSMISSION, SHEET METAL COVER | 1 |
| 2 | FLH-SCH-82 ~375-16 UNC_1_SIMP | FLAT HEAD CAP SCREW 3/8-16 X 1" | 3 |
| 3 | 14829 | MH150 TRANSMISSION, CLUTCH DRIVE ASSEMBLY | 1 |
| 4 | 5.8 ID X 1 IN OD X .075 SHIM | 5/8 ID X 1" OD X .075 SHIM | 1 |
| 5 | 1-1/4 ID X 1-1/2 OD X 1-1/4 LG X 1-3/4 X 3/16 FLANGED | 1-1/4 ID X 1-1/2 OD X 1-1/4 LG X 1-3/4 X 3/16 FLANGED | 2 |
| 6 | 3.4 ID X 1 IN OD X 1 IN LG X 1-1/4 X 3.16 FLANGE | 3/4 ID X 1" OD X 1" LG X 1-1/4 OD X 3/16 FLANGED | 1 |
| 7 | 14864 | MH150 TRANSMISSION, SECONDARY SHAFT BUSHING MODIFIED | 1 |
| 8 | SCH_~375-16 UNC_1_SIMP | SOCKET HEAD CAP SCREW 3/8-16 X 1" | 2 |
| 9 | SCH_~375-16 UNC_1-5_SIMP | SOCKET HEAD CAP SCREW 3/8-16 X 1-1/2" | 1 |
| 10 | HEX NUT_~375-16 UNC_0_SIMP | HEX NUT 3/8-16 | 1 |
| 11 | Z-15GW-B7-K ASSEMBLY | General Purpose Snap Action Switch | 1 |
| 12 | SSCR-HEX-CUP_~250-20 UNC_1_SIMP | SOCKET SET SCREW 1/4-20 X 1" | 1 |
| 13 | HEX NUT_~250-20 UNC_0_SIMP | 1/4-20 NUT | 1 |
| 14 | 1_4 CORD CLAMP | 1/4 INCH CORE CLAMP | 3 |
| 15 | BTNHFD_~164-32 UNC_0-375_SIMP | BUTTON HEAD CAP SCREW 8-32 X 3/8 | 3 |
| 16 | 34inch_SET Collar | 3/4 INCH SET COLLAR | 1 |
| 17 | HEX NUT_~500-13 UNC_0_SIMP | HEX NUT 1/2-13 | 2 |
| 18 | 15145 | M150B TRANSMISSION HEAD SIDE COVER | 1 |
| 19 | BTNHFD_~138-32 UNC_0-25_SIMP | BUTTON HEAD CAP SCREW 6-32 X 1/4" | 4 |
| 20 | 15177 | MH150 TRANSMISSION, REAR PLATE, BRAKE PAD CAP | 1 |
| 21 | SCH_~250-20 UNC_1_SIMP | SOCKET HEAD CAP SCREW 1/4-20 X 1" | 4 |
| 22 | 17496 | CLUTCH BOLT COVER | 1 |
| 23 | SCH_~138-32 UNC_0-5_SIMP | SOCKET HEAD CAP SCREW 6-32 X 1/2" | 4 |

AZTECH CONVERTING SYSTEMS

MH-1500 USER MANUAL



| ITEM NO. | PART NUMBER | DESCRIPTION | CHAIN LIFT/QTY. |
|----------|---|--|-----------------|
| 1 | 14705 | MH150 TRANSMISSION, FRONT PLATE | 1 |
| 2 | 14704 | MH150 TRANSMISSION, REAR PLATE | 1 |
| 3 | 14706 | MH150 TRANSMISSION, STANDOFF | 4 |
| 4 | 14707 | MH150 TRANSMISSION, SHEET METAL COVER | 1 |
| 5 | leeson C4D17FK7D | 12VDC, RPM 1800, HP3/4 | 1 |
| 6 | SCH_-375-16 UNC_0-5_SIMP | SOCKET HEAD CAP SCREW 3/8-16 X 1-1/4" | 8 |
| 7 | FLH-SCH-82_-375-16 UNC_1_SIMP | FLAT HEAD CAP SCREW 3/8-16 X 1" | 4 |
| 8 | 14829 | MH150 TRANSMISSION, CLUTCH DRIVE ASSEMBLY | 1 |
| 9 | 14797 | MH150 TRANSMISSION, SECONDARY SHAFT WELDMENT | 1 |
| 10 | 40B59 5_8 | 40B59 5/8 BORE WITH KEY 40 ROLLER CHAIN | 1 |
| 11 | 14835 | M150 TRANSMISSION SPROCKET ONE WAY CLUTCH ASSEMBLY | 1 |
| 12 | 5_8ID X 7_8OD X 1-1_4 LG X 1-1_8 X 1_8 FLANGED | 5/8 ID X 7/8 OD X 1-1/4 LG X 1-1/8 X 1/8 FLANGED OILITE | 2 |
| 13 | 5_8 ID X 1IN OD X .075 SHIM | 5/8 ID X 1" OD X .075 SHIM | 3 |
| 14 | 40 CHAIN MOTOR TO 1ST SPROCKET | 40 ROLLER CHAIN | 1 |
| 15 | 40 CHAIN 1ST SHAFT TO 2ND SHAFT | 40 ROLLER CHAIN | 1 |
| 16 | 40 CHAIN CLUTCH TO BRAKE | 40 ROLLER CHAIN | 1 |
| 17 | 40 CHAIN 3RD TO 4TH SPROCKET | 40 ROLLER CHAIN | 1 |
| 18 | 14775 | MH150 TRANSMISSION, LOAD CELL WELDMENT | 1 |
| 19 | 14838 | MH150 TRANSMISSION, LOAD CELL CHAF SPRT BLOCK | 1 |
| 20 | 14837 | MH150 TRANSMISSION, CABLE HUB SPRT SHAFT | 1 |
| 21 | 1-1_4 ID X 1-1_2 OD X 1-1_4 LG X 1-3_4 X 3_16 FLANGED | 1-1/4 ID X 1-1/2 OD X 1-1/4 LG X 1-3/4 X 3/16 FLANGED | 2 |
| 22 | 3_4 ID X 1IN OD X 1IN LG X 1-1_4 X 3_16 FAIANGE | 3/4 ID X 1" OD X 1" LG X 1-1/4 OD X 3/16 FLANGED | 1 |
| 23 | 14864 | MH150 TRANSMISSION, SECONDARY SHAFT BUSHING, MODIFIED | 1 |
| 24 | SCH_-375-16 UNC_1_SIMP | SOCKET HEAD CAP SCREW 3/8-16 X 1" | 2 |
| 25 | SCH_-375-16 UNC_1_5_SIMP | SOCKET HEAD CAP SCREW 3/8-16 X 1-1/2" | 1 |
| 26 | HEX NUT_-375-16 UNC_0_SIMP | HEX NUT 3/8-16 | 1 |
| 27 | Z-15GW-87-K ASSEMBLY | General Purpose Snap Action Switch | 1 |
| 28 | SSCR-HEX-CUP_-250-20 UNC_1_SIMP | SOCKET SET SCREW 1/4-20 X 1" | 1 |
| 29 | HEX NUT_-250-20 UNC_0_SIMP | 1/4-20 NUT | 1 |
| 30 | 1_4 CORD CLAMP | 1/4 INCH CORD CLAMP | 6 |
| 31 | BTNHD_-164-32 UNC_0-375_SIMP | BUTTON HEAD CAP SCREW 8-32 X 3/8 | 8 |
| 32 | 34inch_ SET Collar | 3/4 INCH SET COLLAR | 1 |
| 33 | SCH_-138-32 UNC_1_SIMP | SCH 6-32 X 1" | 2 |
| 34 | 1_2 CORD CLAMP | 1/2" CORD CLAMP | 2 |
| 35 | 14793 | MH150 TRANSMISSION, MAIN DRIVE SPROCKET WELDMENT | 1 |
| 36 | HEX NUT_-500-13 UNC_0_SIMP | HEX NUT 1/2-13 | 2 |
| 37 | 15145 | M150B TRANSMISSION HEAD SIDE COVER | 1 |
| 38 | GREASE FITTING 1_4-28 | Steel Grease Fitting, Straight, 1/4"-28 Taper Male, .35/64" Overall Height | 1 |
| 39 | BTNHD_-138-32 UNC_0-25_SIMP | BUTTON HEAD CAP SCREW 6-32 X 1/4" | 4 |
| 40 | 15177 | MH150 TRANSMISSION, REAR PLATE, BRAKE PAD, CAD | 1 |
| 41 | SCH_-250-20 UNC_1_SIMP | SOCKET HEAD CAP SCREW 1/4-20 X 1" | 4 |
| 42 | 15183 | M150 TRANSMISSION DRILL ROD 20 MM ONE WAY CLUTCH SHAFT WELDMENT | 1 |
| 43 | 3_8 FENDER WASHER | FLAT WASHER MCMMASTER CARR | 1 |
| 44 | HEX BOLT_-375-16 UNC_0-5_SIMP | HEX BOLT 3/8-16 X 1/2" GRADE 5 | 1 |
| 45 | SCH_-375-16 UNC_1_SIMP | SOCKET HEAD CAP SCREW 3/8-16 X 1" | 2 |
| 46 | 17496 | CLUTCH BOLT COVER | 1 |
| 47 | SCH_-138-32 UNC_0-5_SIMP | SOCKET HEAD CAP SCREW 6-32 X 1/2" | 4 |







AZTECH CONVERTING SYSTEMS

MH-1500 USER MANUAL

| ITEM NO. | PART NUMBER | DESCRIPTION | QTY. |
|----------|---|--|------|
| 1 | 18035 | MH150B TRANSMISION CHAIN LIFT LOWER SPROCKET WELDMENT 2012 | 1 |
| 2 | 18036 | MH150B TRANSMISION CHAIN LIFT LOWER SPROCKET ASSEMBLY | 1 |
| 3 | 15011 | MH150B TRANSMISION CHAIN LIFT LOWER SPROCKET SHAFT | 2 |
| 4 | 18041 | STERLING SPRING 1832K29 | 1 |
| 5 | 6X292 | Switch,Snap Action With lever | 2 |
| 6 | 15237 | MH150B TRANSMISION CHAIN LIFT LOWER SWITCH CLAMP PLATE | 2 |
| 7 | 18042 | MH150B TRANSMISION LOWER SPROCKET BASE STAND OFF | 2 |
| 8 | 18037 | MH150B TRANSMISION CHAIN LIFT LOWER SPROCKET SIDE PLATE | 1 |
| 9 | 18038 | MH150B TRANSMISION LOWER SPROCKET SIDE PLATE LEFT | 1 |
| 10 | BTNHD_~250-20 UNC_0~5_SIMP | BUTTON HEAD CAP SCREW 1/4-20 X 1/2" | 6 |
| 11 | SCH_~112-40 UNC_0~625_SIMP | SOCKET HEAD CAP SCREW 4-40-5/8" | 4 |
| 12 | FLH-SCH-82_~250-20 UNC_0~5_SIMP | FLAT HEAD CAP SCREW 1/4-20 X 1/2" | 2 |
| 13 | 1_2 ID X 3_4 X OD X .125 THICK SHIMM | ARBOR SHIM 1/2 ID X 3/4 OD X .125 THICK 3088A510 | 2 |






| ITEM NO. | PART NUMBER | DESCRIPTION | QTY. |
|----------|---------------------|---|------|
| 1 | 14798 | MH150 TRANSMISSION, SECONDARY SHAFT | 1 |
| 2 | 14799 | MH150 TRANSMISSION, SECONDARY SHAFT, MACHINED HUB | 1 |
| 3 | 40A45 | 40A45 | 1 |
| 4 | 40BS9 5_8 WO KEYWAY | 40BS9 5/8 BORE 40 ROLLER CHAIN 6793K208 | 1 |

Section 5-3: Sprocket Assembly

| ITEM NO. | PART NUMBER | DESCRIPTION | QTY. |
|----------|-------------|--|------|
| 1 | 14783 | MH150 TRANSMISSION, CLUTCH DRIVE WELDMENT | 1 |
| 2 | 14493 | M150 WINCH JACK SHAFT, BRAKE PAD | 2 |
| 3 | 14832 | MH150 TRANSMISSION, CLUTCH SPRT SHAFT WELDMENT | 1 |
| 4 | 14831 | MH150 TRANSMISSION, CLUTCH DRIVE BRAKE SPROCKET ASSEMBLY | 1 |
| 5 | 14509 | M150 WINCH JACK SHAFT, BRAKE PLATE | 1 |





AZTECH CONVERTING SYSTEMS


MH-1500 USER MANUAL

Section 5-4: Cart Assembly

| ITEM NO. | PART NUMBER | DESCRIPTION | Default/ QTY. |
|----------|-----------------------------------|---|------------------|
| 1 | EXP4352 | MH1500B CUSTOM, 45" INSIDE LEG CLEARANCE, FRAME WELDMENT | 1 |
| 2 | 14703 | MH150 TRANSMISSION, MAIN ASSEMBLY | 1 |
| 3 | 14990 | MH150 TRANSMISSION CHAIN LIFT TROLLEY ASSEMBLY | 1 |
| 4 | 14985 60 ROLLER CHAIN | 60 ROLLER CHAIN | 1 |
| 5 | 13054 | M150 ADJUSTABLE LEG WELDMENT | 2 |
| 6 | 2 x 5 PHENOLIC WHEEL ASSEMBLY | NAME | 2 |
| 7 | 1050-532Z-BOLT ASSEMBLY | NAME | 2 |
| 8 | 6in CASTER ASSM | | 2 |
| 9 | BATTERY BOX | | 1 |
| 10 | WSHR A_.500N | WASHER 1/2 N | 4 |
| 11 | WSHR A_.500 LOCK | 1/2 LOCK WASHER | 4 |
| 12 | 1_2 CORD CLAMP | 1/2" CORD CLAMP | 3 |
| 13 | 14996 | MH80 DETACHABLE FRAME, SOLENOID COVER WELDMENT | 1 |
| 14 | 15375 | RELAY MOUNT BRACKET ASSEMBLY | 1 |
| 15 | 14999 | MH80 DETACHABLE FRAME, SOLENOID MOUNT PLATE | 1 |
| 16 | BTNHD_~250-20 UNC_0~5_SIMP | BUTTON HEAD CAP SCREW 1/4-20 X 1/2" | 2 |
| 17 | BTNHD_~164-32 UNC_0~375_SIMP | BUTTON HEAD CAP SCREW 8-32 X 3/8 | 1 |
| 18 | HEX NUT_.164-32 UNC_0_SIMP | 8-32 NUT | 2 |
| 19 | BTNHD_~164-32 UNC_0~75_SIMP | BUTTON HEAD CAP SCREW GRADE 5 8-32 X 3/4" | 1 |
| 20 | BTNHD_~250-20 UNC_0~75_SIMP | BUTTON HEAD CAP SCREW 1/4-20 X 3/4" | 3 |
| 21 | BTNHD_~250-20 UNC_0~25_SIMP | BUTTON HEAD CAP SCREW 1/4-20 X 1/4" | 4 |
| 22 | FLH-SCH-82_~250-20 UNC_0~375_SIMP | FLAT HEAD CAP SCREW 1/4-20 X 3/8" | 2 |
| 23 | WSHR A_.375N | WASHER 3/8 N | 16 |
| 24 | HEX NUT_.375-16 UNC_0_LOCK | NYLOCK NUT 3/8-16 | 8 |
| 25 | HEX BOLT_~375-16 UNC_1~25_SIMP | HEX BOLT GRADE 5, 3/8-16 X 1-1/4 | 8 |
| 26 | Z-15GW-B7-K ASSEMBLY | General Purpose Snap Action Switch | 1 |
| 27 | SCH_~138-32 UNC_1_SIMP | SCH 6-32 X 1" | 2 |
| 28 | SCH_~164-32 UNC_0~5_SIMP | SOCKET HEAD CAP SCREW 8-32 X 1/2" | 2 |
| 29 | 15189 | Switch Function Momentary On/Off/Momentary On, SPDT | 1 |
| 30 | 18034 | MH150B TRANSMISSION CHAIN LIFT LOWER SPROCKET ASSEMBLY 2012 | 1 |
| 31 | HEX BOLT_~500-13 UNC_1_SIMP | HEX BOLT 1/2-13 X 1" | 4 |
| 32 | 14173 | MH LOAD CELL SPACER BLOCK | 1 |

AZTECH CONVERTING SYSTEMS

MH-1500
USER MANUAL






AZTECH CONVERTING SYSTEMS

MH-1500 USER MANUAL

Section 5-5: Cart Schematic





Section 6: Replacement Parts

6-1: Replacement Casters

FRONT: CAS000-805

REAR w/BRAKE: CAS004-317

6-2: Replacement Electrical Components

Up/Down Relays: 979-1C-12DE (American Zettler)

Load Limit Switch: Z-15GW-B7-K (Omron)

Up/Down Switch: 6X29ZG (Carling)

Load Cell Relay: BU-5083-0000 (American Zettler)



AZTECH CONVERTING SYSTEMS

MH-1500 USER MANUAL

Section 7: Warranties and Service

7-1: Warranties & Provisions

WARRANTIES

All equipment manufactured and sold by AZTECH Converting Systems (Seller) is warranted to be free of defective materials and workmanship under normal use and service for a period of one (1) year from the date of delivery to Buyer's premises. All commercial components not manufactured by Seller carry the original manufacturer's warranty. At Seller's discretion, Seller may provide on-site warranty service for a period of ninety (90) days from the aforementioned date.

REMEDIES

If within the Warranty Period any such Equipment is proven to Seller's satisfaction to be defective in either material or workmanship, Seller, at its sole discretion, shall (a) repair or replace defective parts on the Equipment at Seller's cost, or (b) grant a reasonable allowance on account of such a breach. If within the Warranty Period the Seller receives notice from Buyer of defects in parts or materials. Seller will ship (ground, prepaid) replacement parts and invoice Buyer for the full cost of the replacement parts). Buyer will receive a Return Authorization (RA) from seller, and return defective parts or materials to Seller, who at its sole discretion shall deter-

mine whether defective parts or materials are or are not subject to exclusion from this warranty as provided herein. Any defective parts or material not excluded from the Warranty Period will then be fully credited to Buyer.

EXCLUSIONS

THE FOLLOWING ITEMS ARE EXCLUDED FROM THIS WARRANTY.

- Defects or damage caused by careless or improper use.
- Parts that need periodic replacement from wear during normal operation.
- Routine maintenance and adjustment.
- Failure or damage caused by improper installation or inadequate maintenance by Buyer.
- Failure or damage caused by equipment modifications by Buyer.
- Equipment damage resulting from an accident, or abnormal conditions of operation.

DISCLAIMER

NO OTHER WARRANTY IS EXPRESSED OR IMPLIED INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR ANY PARTICULAR PURPOSE. SELLER IS NOT LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGE SUCH AS, BUT NOT LIMITED TO LOSS IN

PROFITS, LOSS OF USE OF EQUIPMENT, OR INCREASED IN OPERATING COSTS OR EXPENSES.

7-2: Technical Service

In the event that your MH-1500 is not functioning properly or if you have any technical questions, an AzTech Technical Service representative is available to assist you. Contact information is as follows:

Phone: 1-800-829-8351

Fax: 1-480-998-5409

E-Mail: techservice@aztech-converting.com